

SMART MAGNETIC WHITEBOARD WALLPAPERS

APPLICATION GUIDE

HOW TO APPLY **SMART MAGNETIC WHITEBOARD WALLPAPERS**

- **SMART MAGNETIC WHITEBOARD WALLPAPER**
- **SMART MAGNETIC WHITEBOARD WALLPAPER - LOW SHEEN (PROJECTOR)**

Use care when handling your Smart Magnetic Whiteboard Wallpapers. Ensure you do not crease or fold over the material as you may damage the surface. We recommend that you wear gloves.

Please note: two people are required to install SMART MULTIFUNCTION WALLPAPERS

1 HOW TO PREPARE WALLS FOR WALLPAPER APPLICATION

- Cover the floor with plastic or other suitable protection material.
- Remove all previous wallpapers or old / loose paint.
- Check and fill any holes or cracks in the surface with a normal decorators filler.
- Use abrasive paper to sand smooth and rough or uneven surfaces.
- Absorbent surfaces should be treated with a primer, such as **Smart White Primer**, before the application of your Smart Magnetic Whiteboard Wallpaper. Make sure that the primer is fully dry before applying any adhesive to your wall.

2 MEASURE & MARK

- We recommend horizontal application of the wallpaper, starting with the bottom section of the wall.
- With a pencil, mark a straight, level and horizontal line across the wall, 1.22m off the floor. This will guide the top edge of the first section of wallpaper.
- Measure the wallpaper to the desired length and cut with a sharp blade or sharp scissors.

3 HOW TO APPLY THE ADHESIVE

- A Vinyl over Vinyl adhesive is required to install Smart Magnetic Whiteboard Wallpapers. Standard wallpaper adhesives are not suitable. (Please note: Regular Vinyl Adhesive is not suitable for Smart Multi-function Wallpapers, you must use a vinyl over vinyl adhesive like our **Smart Vinyl over Vinyl Wallpaper Adhesive**).
- Add 5% water to the adhesive and stir before using.
- Apply two coats of adhesive. First apply one light coat of adhesive and allow to dry for a minimum of 30 minutes. Then apply a second solid uniform coat of adhesive to the surface with a short pile roller or brush and place the wallcovering, cut to size, in the wet adhesive.

4 APPLY MAGNETIC WHITEBOARD WALLPAPER

4.1 FIRST LENGTH OF MATERIAL:

- Starting in a corner, install the bottom section first, roll the wallpaper out along the wall so that the black side of material is fixed to the wall. Use your pencil line at 1.22m as a guide.
- Carefully roll out the wallpaper along the wall pushing any air and excess adhesive out from behind the material as you go.
- Using the wallpaper spatula provided press the entire surface of the wallpaper to the wall, pushing out all the excess wallpaper adhesive from behind the material.
- Use a consistent and strong pressure to ensure all air bubbles and excess adhesive have been pushed out to the edges. Press the entire surface firmly to the wall.
- Check your first piece of wallpaper is completely free of air bubbles before continuing.

SUPPORT

EMAIL:
support@smartersurfaces.com

PHONE (IRE):
+353 1 412 6200

WEBSITE:
www.smartersurfaces.com

SMART MAGNETIC WHITEBOARD WALLPAPERS

APPLICATION GUIDE

4.2 NEXT LENGTH OF MATERIAL:

There are two jointing options available to you.

• **Butt Jointing (Preferred Method)**

- For jointing the material, we recommend you butt the material together. The material is supplied with clean straight edges which will meet evenly.
- It is important to hang the lower section first so the section applied above will naturally sit on the lower section.
- The material will meet and can be worked together with a wallpaper spatula. Work the material by applying upwards and downwards pressure to each section along the joint bringing them together.
- If an area of the joint requires additional attention, add extra adhesive and continue to work together.
- If the joint / seam is not flat, gently lift the edge of one section of the wallpaper off the wall and guide the material to slot together and work again with spatula. You may need to add a small amount of extra adhesive.
- Check the entire surface of the wallpaper for any excess adhesive or air pockets and push out to an edge with a spatula.
- Make sure to press the entire wallpaper and that each section of wallpaper is free of air bubbles before continuing.

• **Overlap and Double Cut**

- Hang the next section of wallpaper, overlapping the edge of the previous section by 2-3cm.
 - Mark a straight line along the middle of the overlapping section.
 - With a new blade cut along the pencil line and through both layers. Remove the excess material from behind the cut.
 - The two sections will now meet and can be worked together with a wallcovering spatula, apply pressure up and down to each length to bring them together.
- Repeat your chosen method for the entire installation of the wallpaper.

5 INSPECT THE SURFACE

- Wait thirty minutes and visually inspect the surface for bubbles. Use a spatula to push them firmly out to the edge.
- Once wallpaper installation is complete, wipe the entire surface clean with a damp cloth to remove any excess adhesive residue. Finally inspect for any air bubbles.

6 READY TO USE

- Smart Magnetic Whiteboard Wallpapers should not be used for 48 hours following installation to allow adhesive to fully dry.
- Included in your box is a Smarter Surfaces logo. Use this to identify your wall as a writable surface.

USING YOUR SMARTER SURFACE


- For best results, we recommend using high quality accessories, such as those available on our website or from your local Smarter Surfaces partner.
- Clean on a regular basis with a **microfibre cloth** and our cleaning fluids as required.
- Use neodymium magnets such as **SMART NEO-MAGNETS** on magnetic wallpapers.

PRODUCT LIABILITY CLAUSE

The sale of our products is subject to our General Terms and Conditions available on www.smartersurfaces.com

SUPPORT

 **EMAIL:**
support@smartersurfaces.com

 **PHONE (IRE):**
+353 1 412 6200

 **WEBSITE:**
www.smartersurfaces.com